



Process for installation (passageway version)

1. Mortice correct size for case and face plate.
2. Drill holes for spindle and through-bolts.
3. Screw face plate (KK2248-BC-00-2934) into place using 3.5mm SS screws
4. Remove rose outer from both levers.
5. Insert spindle (8mmx 90mm LOA - KX1625-0000-2714) through door and latch.
6. Place external lever on spindle with 47mm through bolt (KX1625-0000-2924).
7. Locate and tighten through bolts (one from each side).
8. Replace rose outer on both levers.
9. Tighten grub screw on underside of each lever.
10. Mortice for and install strike plate with dust box (KK2248-BC00-2921) using 3.0mm SS screws

