



Process for installation (privacy version)

1. Mortice correct size for case and face plate.
2. Drill holes for spindle, privacy button and through-bolts.
3. Screw face plate (KK2248-BC-00-2934) into place using 3.5mm SS screws
4. Remove rose outer from both levers.
5. Insert spindle (8mmx 90mm LOA - KX1625-0000-2714) through door and latch.
6. Place external lever on spindle with 47mm through bolt (KX1625-0000-2924).
7. Place cup (KK2248-BU00-2922) on the square privacy shaft on internal side (cup over shaft).
8. Put privacy pin through rose and place **M4 nut (45404)** on privacy pin (KK2248-BC00-2918) and screw up to stop.
9. Place internal lever on spindle and screw push pin into square shaft (through cap).
10. Locate and tighten through bolts (one from each side).
11. Replace rose outer on both levers.
12. Tighten grub screw on underside of each lever.
13. Mortice for and install strike plate with dust box (KK2248-BC00-2921) using 3.0mm SS screws

