

## METRIC to IMPERIAL / IMPERIAL to METRIC CONVERSION

To convert millimetres to inches - divide mm by 25.4

Or visit - <https://www.rapidtables.com/convert/length/mm-to-inch.html>

To convert inches to millimetres - multiply inches by 25.4

Or visit - <https://www.rapidtables.com/convert/length/inch-to-mm.html>

METRIC		IMPERIAL
4 mm	=	5/32"
6 mm	=	15/64"
10 mm	=	25/64"
12 mm	=	15/32"
15 mm	=	19/32"
16 mm	=	5/8"
18 mm	=	45/64"
19 mm	=	3/4"
22 mm	=	55/64"
25 mm	=	63/64"
30 mm	=	1-3/16"
31 mm	=	1-7/32"
32 mm	=	1-17/64"
34 mm	=	1-11/32"
35 mm	=	1-3/8"
38 mm	=	1-1/2"
40 mm	=	1-37/64"
41 mm	=	1-39/64"
45 mm	=	1-49/64"
47 mm	=	1-27/32"
50 mm	=	1-31/32"
52 mm	=	2-3/64"
55 mm	=	2-11/64"
57 mm	=	2-1/4"
58 mm	=	2-9/32"
60 mm	=	2-23/64"
62 mm	=	2-7/16"
64 mm	=	2-33/64"
69 mm	=	2-23/32"

METRIC		IMPERIAL
70 mm	=	2-3/4"
72 mm	=	2-53/64"
75 mm	=	2-61/64"
80 mm	=	3-5/32"
90 mm	=	3-35/64"
92 mm	=	3-5/8"
94 mm	=	3-45/64"
95 mm	=	3-47/64"
96 mm	=	3-25/32"
101 mm	=	3-31/32"
120 mm	=	4-23/32"
128 mm	=	5-3/64"
136 mm	=	5-23/64"
140 mm	=	5-33/64"
160 mm	=	6-19/64"
165 mm	=	6-1/2"
168 mm	=	6-39/64"
178 mm	=	7-1/64"
190 mm	=	7-31/64"
192 mm	=	7-9/16"
196 mm	=	7-23/32"
200 mm	=	7-7/8"
224 mm	=	8-13/16"
232 mm	=	9-9/64"
240 mm	=	9-29/64"
241 mm	=	9-31/64"
245 mm	=	9-41/64"
250 mm	=	9-27/32"
254 mm	=	10"

METRIC		IMPERIAL
256 mm	=	10-5/64"
260 mm	=	10-15/64"
264 mm	=	10-25/64"
281 mm	=	11-1/16"
288 mm	=	11-11/32"
290 mm	=	11-27/64"
296 mm	=	11-21/32"
300 mm	=	11-13/16"
396 mm	=	15-19/32"
400 mm	=	15-3/4"
496 mm	=	19-17/32"
500 mm	=	19-11/16"
596 mm	=	23-15/32"
600 mm	=	23-5/8"
620 mm	=	24-13/32"
700 mm	=	27-9/16"
800 mm	=	31-1/2"
896 mm	=	35-9/32"
900 mm	=	35-7/16"
1000 mm	=	39-3/8"
1120 mm	=	44-3/32"
1200 mm	=	47-1/4"
1296 mm	=	51-1/32"
1600 mm	=	62-63/64"
1620 mm	=	63-25/32"
1696 mm	=	66-49/64"
1750 mm	=	68-57/64"
1800 mm	=	70-55/64"
2000 mm	=	78-47/64"