


## HOW TO DRESS YOUR WINDOWS

In the UK there are two main styles of window.


1. **Sash window.** A two-piece window comprising of top and bottom sections which move independently of each other. Most common in Georgian and Victorian properties.
2. **Casement windows.** Are generally side hung on hinges and open outwards. Many have small top hung venting window known as a fanlight.

### Sash windows



### Casement windows

Apart from changing the finishes, to our knowledge, casement window furniture has not been re-designed since Victorian times . . . until now.



Modern casement windows may be fitted with an integral espagnolette system (morticed into the leading edge of the window). These can be operated by the handles shown on page 26 of our brochure. Please call for details.

**Tips**

Match your window fittings with your door and cabinet hardware (see collection shots, pages 28 to 31). If using blinds, the design and finish can follow through on your blind pull (page 51).